

Activating AllStream Now on Roku Streaming Stick 4K




Instructions for your Roku Streaming Stick 4K may vary depending on its model and software version.

Getting Started

You will need these items before you begin:

1. Roku Streaming Stick 4K and Remote
2. Roku Account Login Information (If you don't have a Roku account, you can sign up for one for free at roku.com)
3. Wi-Fi password
4. AllStream Login and Passphrase. Alliance should have emailed this to you, or you can generate a new one from a device that already has AllStream activated on it. Call us at (605) 582-6311 if you need help.


Let's get started



STEP 1: Connect your streaming player

Plug the USB power cable into your streaming player. We recommend keeping the power cable coiled in the velcro wrap.

TIP:
For help setting up your device, visit go.roku.com/rss4k



STEP 2: Connect to TV

For the best streaming experience, use the included USB power cable and power adaptor to connect your streaming player to a wall outlet.

DOESN'T FIT? Order a free HDMI extender cable at my.roku.com/hdmi



Or use the included USB power cable to connect to the USB port on your TV.

See **Wi-Fi® tips** on the back of this guide for more information.

NOTE: See a red light on your streaming player?

That means the USB port on your TV is not providing enough power. Use the included power adaptor instead.



STEP 3: Select input

Use your TV remote to power on your TV and select the input (source) you used to connect your streaming player.

4



STEP 4: Pair your remote

Pull out the battery tab on the back of your remote. It will pair to your streaming player automatically.

TIP:

For more help, visit go.roku.com/remotepair

5



STEP 5: Follow on-screen setup

Follow the instructions on your TV screen. Activate your streaming player by using your computer or smartphone to link a Roku account.

IMPORTANT:

Roku never charges for activation support.

Tips for better Wi-Fi® performance



Back of TV*

DO

For the best performance, separate the Wi-Fi® receiver from other cables behind your TV.



Back of TV*

DO NOT

To minimize interference, do not place the Wi-Fi® receiver near exposed input ports or resting on other electronic devices.

*For illustration only

Using your remote to navigate

D-Pad: A directional ring (up, down, left right) used to move through app tiles and menus.

OK Button: The center button inside the D-Pad used to select items.

To return to the main Roku Home Screen, press the Home button from any app.

Press the Back button to move back to the previous screen.

Options opens a small menu with extra settings or choices for whatever is currently on your screen.




Channel shortcut buttons may vary

Roku Streaming Stick 4K

Setting up your Roku Streaming Stick 4K



Plug the Roku Streaming Stick 4K into your TV. Using your Roku remote, press the Play/Pause button to start. Then choose your language and press the OK button.





The Roku Streaming Stick will perform a Wireless scan to look for available wireless networks.



Choose your Wi-Fi network and press the OK button on the remote. Enter your Wi-Fi password and select Connect.




Your Roku Streaming Stick 4K will check for any software updates. Update, if available.





Activating AllStream Now on Roku Streaming Stick 4K




Next, it will ask you to sign in or create your Roku account. If you already have a Roku account, enter the email you used when you set up your account. Follow the on-screen instructions to log in. Roku never charges for activation support.



You can also activate with the QR code. Use your mobile device camera to scan the QR code. A window will appear on your phone or tablet to activate your new Roku device. If you are an existing customer, follow the link to sign in. Otherwise, complete the required fields to create your free Roku account.




There may be additional screens asking you to name your device and verify or confirm information. Complete any required fields to continue.




Your TV screen will automatically update based on your selections.




Continue to follow the additional screens on your mobile device until you receive confirmation that your setup is complete. Your TV screen will automatically refresh.





Now that your Roku Streaming Stick is set up, let's add AllStream. From the Home Screen, navigate to the Search (magnifying glass) using your Roku remote. Type in AllStream Now. Navigate to the right to select AllStream Now from your search results. Download and install the app.



Activating AllStream Now on Roku Streaming Stick 4K



Enter the AllStream Login and Passphrase you received from Alliance Communications. Select OK after entering both your Login and Passphrase.



Once validated, the onscreen programming guide for AllStream will appear. Select the program you want to watch to begin.




How to Activate AllStream Now on Additional Devices Using your Roku Streaming Stick 4K

You can add AllStream Now to more supported devices by generating a new login and passphrase. From a Roku Streaming Stick device that has active AllStream service, open your AllStream Now app.

With the AllStream programming guide active on your screen, press the back button on your Roku Streaming Stick remote to open the Tab bar. Select Settings from the Tab bar.



In Settings, select Manage Account. Then, arrow down and select Add Device.



A new Login and Passphrase will display on your screen. Use that information when activating AllStream on additional devices.



AllStream Now Support Resources

[User Guides](#)

[Video Tutorials](#)

Dial 611 from any phone with Alliance service or call (605) 582-6311.